

INTRODUCING XT21-AI

Stronger. Sturdier. And built to perform.

Our Extended Time animal insemination refrigerator is designed for long-term storage at cryogenic temperatures under rugged conditions.

Innovative features that work harder for you:

- **Rugged Construction** – Ribbed high-strength aluminum body
- **Durable Design** – Improved magneformed neck tube for demanding field use
- **Convenient Storage** – Numbered canister index ring and tapered internal spider
- **Superior Vacuum Performance** – Added super insulation for maximum holding times
- **Reliable** – Designed and built to stringent specifications, backed by a five-year vacuum warranty

Further enhance your XT21-AI with optional accessories:

- Liquid Nitrogen low-level alarm
- Convenient roller base



Distributed By:
Med-Tech Gases, Inc.
1-800-FINE-GAS (346-3427)
www.medtechgases.com



XT21-AI



Model		XT21-AI
Static Holding Time Days ⁽¹⁾		221
Working Time Days ⁽²⁾		138
Evaporation Rate ⁽¹⁾ liters/days		0.095
Liquid Nitrogen Capacity – liters		21
Weight Empty	lbs.	26
	kg.	11.8
Weight Full ⁽³⁾	lbs.	63.4
	kg.	28.8
Neck Diameter	in.	2.18
	mm.	55.4
Overall Height	in.	25.8
	mm.	655
Overall Diameter	in.	15.6
	mm.	396
Number of Canisters		6
Canister Dimensions	in.	1.65x11
	mm.	41.9x279
Number of 1.2 ml & 2.0 ml vials – (5/cane)		210
Number of ½ cc straws – (10/cane)		720
Number of 1.2 cc straws – Bulk (1 level)		1122
Optional accessories		
Roller Base		R018-8C00
Low-Level Alarm		R021-8C15

- (1) Evaporation Rate and Static Holding Time are nominal. Actual rate may be affected by the nature of the contents, atmospheric conditions, container history and manufacturing tolerances.
 (2) Work Time is arbitrary, reference-only value to estimate container performance under the actual operating conditions.
 (3) Without canisters.



Taylor-Wharton

A legacy of excellence. A vision of promise.



SINCE
1961

Distributed By:
Med-Tech Gases, Inc.
 1-800-FINE-GAS (346-3427)
www.medtechgases.com